

Table of Contents

Table of Contents	1
Opening a band gap in silicene and bilayer graphene with an electric field	2
Bilayer graphene	2
Building a bilayer graphene structure	2
Calculation and analysis	6
Silicene	13
Optimizing the geometry	14
Band structure	17
References	20
More reading	20

[Try it!](#)[QuantumATK](#)[Contact](#)[Docs](#) » [Tutorials](#) » [Graphene and other 2D materials](#) »

Opening a band gap in silicene and bilayer graphene with an electric field

Opening a band gap in silicene and bilayer graphene with an electric field

Version: 2017

Downloads & Links



PDF


[Introduction to QuantumATK](#)
[ATK Reference Manual](#)


In this tutorial you will learn how to insert metallic gate electrodes in an QuantumATK bulk calculation and use them to apply electric fields. You will use these features to study the opening of a band gap in bilayer graphene and in silicene under the presence of an electric field. It is assumed that you are familiar with the basic functionalities of **QuantumATK**.



Bilayer graphene

Building a bilayer graphene structure

1. Create a new empty project and open **Builder** (icon .
2. Insert graphite (not graphene!) from **Database**.
3. Open Bulk Tools ► Lattice Parameters. Select Cartesian coordinates and set the value of *c* lattice constant to be 25 Å.



×

–

□

Lattice Parameters

Choose the lattice type from the dropdown menu.

Lattice type: Hexagonal

Keep Cartesian coordinates constant when changing the lattice

Lattice Parameters

Adjust the lattice parameters of the selected lattice type. Only parameters relevant for the lattice type can be changed. Lattice parameters can be exported to the clipboard by right-clicking.

a (Å) 2.4612
 α 90

b (Å) 2.4612
 β 90
 b/a 1

c (Å) 25
 γ 120
 c/a 10.1576


Primitive Vectors

Manipulate the Primitive Vectors directly. This is only possible if UnitCell was chosen from the dropdown menu.


	x (Å)	y (Å)	z (Å)
A	1.2306	-2.13146	0
B	1.2306	2.13146	0
C	0	0	25

Volume = 131.149 Å³

- Go to Coordinate Tools ► Center and click “Apply” to center the system.



5. To insert the metal electrodes, open Miscellaneous ► Spatial Regions..., right-click the table (the area under the headers Region Type/Value) and click "Insert region" twice.
6. Set the voltage to 0 V for the first metallic region, and 10 V for the second. Change their size so that they cover the entire hexagonal unit cell (see the figure below). It does not matter if the regions stick outside the cell, those parts will be ignored in the calculation anyway.




The applied voltage results in 4 V/nm in the z direction, just above the field that has been found in experiments to open a band gap.


Calculation and analysis

We will then analyze the band structure of the graphene bilayer under the static electric field.

1. Send the graphene bilayer structure to **Script Generator**.
2. Insert a **New Calculator** block




3. Open the **New Calculator** block, and choose the "*ATK-SE: Extended Hückel*" method. For good accuracy, set the k-points to be 9x9x1.
4. Under "*Huckel basis set*" select the "*Cerda. Carbon [graphite]*" basis set, which describes the sp² bonding of graphene very well.
5. Untick the "*No SCF iteration*" option to carry out the computation self-consistently.



Warning

It is extremely important to include self-consistency; otherwise the field will not have any effect at all!


6. Go to "*Poisson solver*", set "*Multi-grid*" in **Solver**, and choose "*Dirichlet*" in **Boundary Conditions** on both sides in the C direction.




Note

For this particular calculation, you can choose any boundary condition in the C direction since the metal gates will fix the potential at the boundaries anyway, but "*Dirichlet*" is the physically correct condition when a constant value of the potential is desired at the boundary.


7. Add a **Bandstructure** block by clicking Analysis ► Bandstructure.



8. Double-click the **Bandstructure** block and change the route to G, M, K, G. Also increase the number of points per segment to 200.





9. Name the output file "*bilayer_graphene_efield.nc*".




10. Send the calculation to **Job Manager**, save the Python script in the window that appears and run the calculation. It should take no more than 20-30 seconds to run.

After the calculation, visualize the band structure and zoom in around the K point, where a band gap is opening with increasing the strength of the electric field. The following figures, from top to bottom, show the band structure of the bilayer graphene with an applied electric field of 0, 10, and 20 Volts, respectively.








Note


- You can use DFT as well, the results will be similar.
- No attention was paid to the interlayer distance. You can change it a bit to see how the band structure changes. Note, however, that you cannot use DFT/GGA to optimize this distance because no energy minimum will be found, due to the absence of dispersion corrections (the layers are bound by Van der Waals forces, not captured in standard GGA). LDA works, fortuitously, because of a cancellation of errors, but the results cannot really be trusted.


Silicene

To study the effect of electric fields on silicene you first need a good model of this material. The approach will be to start with graphene and turn it into silicene, optimize the geometry, and then repeat the same steps followed to calculate the bilayer graphene under the presence of an electric field.






Optimizing the geometry



1. In **Builder**, add graphene (not graphite this time) from **Database** to **Stash** following the same steps explained above for the bilayer graphene.
2. Change the two C atoms to Si by selecting them (using the left mouse button while holding down the **Ctrl** button of your keyboard) and using the "*Periodic Table*" tool .
3. The lattice constant of silicene is not the same as for graphene, but rather than guess it, it will simply be part of the geometry optimization to determine it. To start from a reasonable guess, click **Bulk Tools** ► **Lattice Parameters**. Make sure to keep the fractional coordinates constant, set the lattice parameter a to be 3.8 Å and increase the c lattice parameter to 20 Å.




4. In Builder, go to Coordinate Tools ► Center, in order to center the configuration.



5. The flat geometry where both Si atoms are in the same plane is a local minimum in the potential energy surface. Therefore, click the "Rattle" tool  a few times to add a small perturbation to the coordinates. This ensures that the geometry optimization will converge to the global minimum.
6. Send the geometry to Script Generator by using the "Send To" button .
7. In Script Generator, insert New Calculator and OptimizeGeometry blocks by double-clicking the icons in the Blocks panel:

-  New Calculator.
-  Optimization ► OptimizeGeometry.

8. Use 21x21x1 k-points for good accuracy, and choose GGA-PBE for exchange-correlation. You can in principle use the default DoubleZetaPolarized basis set, but here you will use the “Tight Tier 1” basis set, which provides slightly better results.



New Calculator

Calculators

- ☒ ATK-DFT
- ☐ ATK-SE: Extended Hückel
- ☐ ATK-SE: Slater-Koster
- ☐ ATK-Classical
- ☐ Abinit
- ☐ FHI-aims

Calculator settings

- Algorithm parameters
- Basic
- Iteration control parameters
- Basis set/exchange correlation**
- Numerical accuracy parameters
- Poisson solver

Exchange Correlation

Type: GGA

Predefined functionals: PBE

Exchange: PerdewBurkeErnzerhofExchange

Correlation: PerdewBurkeErnzerhofCorrelation

Parameters

Hubbard U: Disabled

Spin: Unpolarized


Van der Waals correction: Disabled

Basis Set

Element	Pseudopotential	Basis Set
Silicon	FHI [Z=4] GGA.PBE	Tight Tier 1

Buttons: Estimate Memory Usage, Activate tags, Add element, OK


9. In the **OptimizeGeometry** block, set the force tolerance to be small (0.01 eV/\AA) and the stress tolerance to be even smaller (0.0005 eV/\AA^3). Unconstrain the cell in the x and y directions.



10. Name the output file "*silicene_optimize.nc*" and save the Python script.
11. Send the script to **Job Manager**, save the script and run the job. The calculation will take about 10 minutes. When it finishes, drop the Bulk Configuration with ID "*gID001*" on **Builder**, and inspect the geometry. You will find a nicely optimized silicene sheet with a buckling of about 0.5 Å and an optimized lattice constant of 3.86 Å. Both values are in good agreement with those reported in the literature in [\[1\]](#) and [\[2\]](#).

Band structure


Using the optimized structure, repeat the steps above for the bilayer graphene to insert metallic gates and compute the band structure with electric fields. Notice that, in the case of silicene, you need to make the spatial region larger in the XY plane, since the cell is also larger. Use 20 V as the voltage on the second electrode.




Note

You should use the same calculator settings as for the optimization. The calculation will take less than a minute.

In the plot below you can see the band structure at zero field (top) and with 20 V applied on the gate (bottom), which produces a band gap of about 0.1 eV. By trying different values of the voltage you will find that the band gap increases essentially linearly with the field as shown in [\[3\]](#).





Notice that in this case, if you look closely, the band gap is not exactly at the K point.

Note

If you apply a transverse field to a single graphene layer, no gap opens up. The reason is that the graphene is completely flat, and so the field just gives a constant shift of the potential. In the case of silicene the gap appears because the sheet is naturally buckled.

References

- [1] S. Cahangirov, M. Topsakal, E. Akturk, H. Sahin, and S. Ciraci, Two- and One-Dimensional Honeycomb Structures of Silicon and Germanium, *Physical Review Letters* 102, 236804 (2009)
- [2] N. D. Drummond, V. Zolyomi, and V. I. Fal'ko, Electrically tunable band gap in silicene, *Physical Review B* 85, 075423 (2012)
- [3] R. Zhou, "Structural And Electronic Properties of Two-Dimensional Silicene, Graphene, and Related Structures", Master Thesis, Wright State University, Electrical Engineering, Dayton OH, USA (2012)

More reading


- Z. Ni et al., "Tunable Bandgap in Silicene and Germanene", *Nano Letters* 12, 113-118 (2011)

- C. Xu et al., "Giant magnetoresistance in silicene nanoribbons", *Nanoscale* 4, 3111-3117 (2012)
- Y. Wang et al., "Half-metallic Silicene And Germanene Nanoribbons. Towards High-performance Spintronics Device", *Nano* 7, 1250037 (2012)
- L. Pan et al., "Thermoelectric properties of armchair and zigzag silicene nanoribbons", *Phys. Chem. Chem. Phys.* 14, 13588 (2012)
- H. Li et al., "High performance silicene nanoribbon field effect transistors with current saturation", *European Physical Journal B* 85, 1 (2012)
- R. Quhe et al., "Tunable and sizable band gap in silicene by surface adsorption", *Sci. Rep.* 2, 853 (2012)

For a similar study on hexagonal boron-nitride (hBN), see

- K. Tang et al., "Electronic and transport properties of a biased multilayer hexagonal boron nitride", *European Physical Journal B* 85, 301 (2012)

 Previous

Next 

© Copyright 2023 Synopsys, Inc. All Rights Reserved.